

SLIDE AND BLOCK

SHIP ROOM TEMPERATURE



Place the slide containers and/or blocks into the room temperature specimen bag.



Insert cold pack and specimen bag into the foil pack and seal. The cold pack is used to prevent melting of paraffin block specimens.



Place foil pack containing the specimens in box along with completed requisition, clinical history form or notes, Pathology report, and/or other applicable paperwork. Transport in this box for tracking.